



# Finnmark 2

## Tips & Tricks

# Congratulations!


We wish you lots of fun with your new Nordisk tent!



Spread out the inner tent. Position the yellow poles diagonally across the tent. The silver pole is not required until later! Ensure all doors are closed.




Ensure an even surface without any sharp objects!




**E**

Fix the pole ends into the webbing eyelets on the inner tent and secure them by clipping on the hooks. The tent is now free standing and can easily be positioned in the wanted position.

**F**

Secure the tent to the ground by attaching pegs onto each webbing loop, starting with the rear corners and fasten the silver pole to the center of inner tent.



**4**

Position the fly sheet over the inner tent. Connect the fly sheet by joining the colored buckle on fly sheet with the matching buckle color on inner tent. Secure the silver pole to the fly sheet by connecting it to the flysheet pockets (can be a little tight). Now place and secure the flysheet to the poles with the velcro straps. Continue by connecting the rest of the buckles until the fly sheet is positioned on top of the inner tent.

**5**

Secure the tent by attaching the guy ropes to the ground. Depending on weather conditions judge how many guy ropes that are needed. In stormy weather the tent must be securely fastend. Adjust webbings and guy ropes for correct tension.



# Trek · Camp · Live

– take care of your Nordisk tent!

## Before Trek

- build up the tent from home and **check if everything is ok.**
- **know the environment** you'll go to (sand, hard soil, snow), and check that pegs etc. matches this
- consider to bring along a **footprint**
- **check that the poles are ok**, and if not; buy a new set before you go
- **bring along a repair kit** incl. an outer tube for poles and tape for broken seams etc.
- make sure the **tent is clean**
- ensure that **zippers runs smoothly** (if not, get some silicone spray)
- if trekking in very wet conditions, **seal the seams** with a seam sealer, but check if it is SI or PU
- do not overfill your packsack as you might need the **extra space** during the trip
- **optimize weight** by leaving pegs, inner cabin etc. at home if it's not needed on the trip
- **compress the packsack** as much as possible

## In the Camp

- make sure you **pitch on an even surface**. Some models depends on this for optimal ventilation
- **do not camp in too high grass** if you want floor level ventilation
- **remove sharp rocks and sticks** that could harm the tent floor (i.e. use footprint)
- **stretch the tent as much as possible** for optimal strength and water repellency
- if wet or very windy, you need to **re-adjust the tension of the guy ropes**
- if very windy, **use extra guy ropes and pegs** for stability
- **put the packsack somewhere where you can find it again** (i.e. mesh pockets inside the tent)
- **avoid fire and smoke** near the tent – be aware of wind directions!
- keep an eye on **guy rope tension** once in a while
- the pack sack is a little bigger than necessary in case of an emergency pack down
- **remove all traces from your camp**

## Living with your tent

- **keep it clean** by hosing it after use, if very dirty. But don't use high pressure
- **clean it with a soft sponge**
- use **no harsh chemical cleaning** or machine washing
- **keep it dry**, and if packed down wet, remember to dry it as soon as possible  
– remember that a wet tent is heavier than a dry one
- **check guy ropes and pegs** once in a while, and buy new ones if damaged
- if you have **damaged poles**, your local Nordisk dealer can supply new ones
- be aware that long **exposure of sunlight** can **degrade the fabric**
- if you want floor in your apsis, you can **purchase a tailored footprint**
- love and nurse your tent. **If you protect your tent, it will protect you**

You can find more information on [nordisk.eu](http://nordisk.eu)

## Tips & Tricks

- 1 You can purchase a ground sheet for your tent, if you need floor in the vestibule
- 2 Finnmark can stand with inner tent alone, i.e. as a beach tent or to look at the stars at night.
- 3 For extra storage, you can purchase a ceiling storage net for the top of your inner cabin
- 4 The doors come with magnetic parts, so you can attach these to the roof section (quick openings)
- 5 Tighten or loosen the guy ropes on the ventilation arch, to adjust ventilation in the tent
- 6 You can adjust the height and the ventilation, just by pulling the webbings found near the poles.
- 7 The pack sack is made a little bigger than necessary in case of an emergency pack down  
– you can adjust the pack size with the tension buckles.



Scan it!

For 360° View, Windtest,  
How to pitch & Fact sheet





[www.nordisk.eu](http://www.nordisk.eu)

#### Nordisk Company

Papirfabrikken 74  
DK-8600 Silkeborg  
Tel. +45 7373 4000  
Fax +45 7373 8015  
info@nordisk.eu

Denmark, International

#### Nordisk Freizeit

Max-Weber-Strasse 16  
D-25451 Quickborn  
Tel. +49 (0) 4106 76770  
Fax +49 (0) 4106 767714  
info@nordisk.de

Germany, Austria, Switzerland

#### Nordisk Asia

Unit 904, Zhong Rong Heng Rui  
West Tower  
560 Zhang Yang Road  
CN-200122 Shanghai  
Tel. +86 13901625206  
jpo@nordisk.eu  
China, Taiwan, Hongkong