



Svalbard 1 PU

Build up Instructions



See more online:

Svalbard 1 video · Build-up video · 360° pics · Windtest

Congratulations!


We wish you lots of fun with your new Nordisk tent!



Spread out the tent. Slide the poles through the color coded pole sleeves. Ensure all doors are closed.





Ensure an even surface without any sharp objects!



F

Fix the pole ends into the webbing eyelets on the inner tent. Secure the tent to the ground by attaching pegs into each webbing loop, starting with the rear corners.


**F**

Lift up the pole channel to erect the tent. Mount the remaining pegs to the ground.



4

Position the fly sheet over the inner tent. Connect the fly sheet by joining the colored buckle on fly sheet with the matching buckle color on inner tent. Use velcro to attach fly sheet to poles. Continue by connecting the rest of the buckles until the fly sheet is positioned on top of the inner tent.

**5**

Erect the tent by attaching the guy ropes to the ground. Depending on weather conditions judge how many guy ropes that are needed. In stormy weather the tent must be securely fastend. Adjust webbings and guy ropes for correct tension.



Trek · Camp · Live

– take care of your Nordisk tent!

Before Trek

- build up the tent from home and **check if everything is ok.**
- **know the environment** you'll go to (sand, hard soil, snow), and check that pegs etc. matches this
- consider to bring along a **footprint**
- **check that the poles are ok**, and if not; buy a new set before you go
- **bring along a repair kit** incl. an outer tube for poles and tape for broken seams etc.
- make sure the **tent is clean**
- ensure that **zippers runs smoothly** (if not, get some silicone spray)
- if trekking in very wet conditions, **seal the seams** with a seam sealer, but check if it is SI or PU
- do not overfill your pack sack as you might need the **extra space** during the trip
- **optimize weight** by leaving pegs, inner cabin etc. at home if it's not needed on the trip
- **compress the pack sack** as much as possible

In the Camp

- make sure you **pitch on an even surface**. Some models depends on this for optimal ventilation
- **do not camp in too high grass** if you want floor level ventilation
- **remove sharp rocks and sticks** that could harm the tent floor (i.e. use footprint)
- **stretch the tent as much as possible** for optimal strength and water repellency
- if wet or very windy, you need to **re-adjust the tension of the guy ropes**
- if very windy, **use extra guy ropes and pegs** for stability
- **put the pack sack somewhere where you can find it again** (i.e. mesh pockets inside the tent)
- **avoid fire and smoke** near the tent – be aware of wind directions!
- keep an eye on **guy rope tension** once in a while
- the pack sack is a little bigger than necessary in case of an emergency pack down
- **remove all traces from your camp**

Living with your tent

- **keep it clean** by hosing it after use, if very dirty. But don't use high pressure
- **clean it with a soft sponge**
- use **no harsh chemical cleaning** or machine washing
- **keep it dry**, and if packed down wet, remember to dry it as soon as possible
 - remember that a wet tent is heavier than a dry one
- **check guy ropes and pegs** once in a while, and buy new ones if damaged
- if you have **damaged poles**, your local Nordisk dealer can supply new ones
- be aware that long **exposure of sunlight can degrade the fabric**
- if you want floor in your apsis, you can **purchase a tailored footprint**
- love and nurse your tent. **If you protect your tent, it will protect you**

You can find more information on nordisk.eu



Scan it!

For 360° View, Windtest,
How to pitch & Fact sheet

NORDISK®



Tips & Tricks

- 1 When you open a door, you can fold and store it, in the mesh pockets found near the door.
- 2 You can adjust the height and the ventilation, just by pulling the webbings found near the poles.
- 3 You can open the door and attach a tarp as an exit/entry extension.
 - please see our tarp collection at nordisk.eu
- 4 If you secure the „wind king“ probably it can withstand hurricane wind.
- 5 The pack sack is made a little bigger than necessary in case of an emergency pack down
 - you can adjust the pack size with the tension buckles.



www.nordisk.eu

Nordisk Company A/S

Papirfabrikken 74
DK 8600 Silkeborg
Denmark
info@nordisk.de
Tel. +45 73 73 40 00

Nordisk Freizeit GmbH

Max-Weber-Straße 16
D-25451 Quickborn
Germany
info@nordisk.de
Tel. +49 (0) 4106 / 76 77-0

Nordisk Asia

Unit 904, Zhong Rong Heng
Rui West Tower, 560 Zang Yang Road
CN-200122 Shanghai
China
Tel. +86 21 5836 3068

Nordisk Japan Co. Ltd.

2F, 2-8-11, Nishi-Azabu,
Minato-ku,
Tokyo 106-0031,
Japan
Tel. +81(0) 3 6885 8206